




Scan the QR code to watch the shooting bracket assembly and instruction video

Assembly instructions




Step 1:

Stretch the telescopic rod then rotate to fix, and insert it into the 2 holes corresponding to the rear bracket and fix it with the large screws.

Step 2:


Insert the telescopic rod into the 2 holes corresponding to the front bracket, then insert the small screws in the 2 holes at the bottom and finally turn the rod to the right to fix it.



Step 3:

Loosen the screw knob, turn the adjusting knob into the spring bracket and then insert the spring bracket (Note: with the patch facing forward) into the holes to complete the assembly.

Instruction Manual




Adjustment length

Turn the knob to loosen it, pull the telescopic lever to the length you want, then reverse the knob to lock it.

Adjustment height

Turn the height adjustment knob to the left to raise the height of the front bracket, then turn the screw button underneath to secure the front bracket.



Turn down the height

First loosen the bottom screw button, then turn the height knob to the right and finally press the front bracket downwards with your hand.