WULF

MONOLUX IR ILLUMINATOR MANUAL

RESEARCH | DEVELOPMENT | PRECISION #IAMWULF

WHAT'S IN THE BOX

- Wulf Monolux
- Wulf Battery Charger & Cable
- Remote Dimmer Switch
- 18650 3000 mah battery
- Picatinny Rail Mount
- White LED Module
- Red LED Module
- IR850 LED Module (Pre-installed)

BATTERY INSTALLATION

- 1. Unscrew the rear end cap from the unit.
- 2. Place the fully charged battery into the main body of the torch.
- Screw the rear end cap back on to the torch.

MOUNTING THE TORCH

- 1. Unscrew all the screws on the mount provided.
- 2. Place the torch into the mount and tighten all the screws up.
- 3. Attach the base of the mount to a Picatinny/Weaver system.

WÜLF

OPERATION

- 1. Once installed and mounted, firmly press the button on the rear of the torch to turn on. Repeat to turn the torch off.
- Alternatively, install the Remote Dimmer Switch onto the back of the unit and turn the torch on via the switch you have placed on your rifle.
- 3. To adjust the brightness, turn the dial on the back of the torch OR lightly press the Remote Dimmer Switch.
- 4. To adjust the focus of the beam, whilst holding the torch head, rotate the body of the torch clockwise, this will increase the length of the tube making the beam wider.

Please Note: On first attempt this will be tight, so it is recommended that you make sure the head of the torch is on securely.



CHANGING THE LIGHT PILLS (SOLD SEPARATELY)

- 1. Holding the torch in two hands, unscrew torch head from body.
- 2. Unscrew the brass pill currently installed in the unit.
- 3. Install desired brass pill.
- 4. Re-install torch head, ensuring it is on tight.
- 5. Operate torch as normal.

WWW.WULFOPTICS.COM #IAMWULF

WÜLF